

- 16) Swab tested well at rate of 2 bbls. fluid/hr., 50% oil, 50% water.
- 17) Reset RBP at 1885'.
- 18) Perforated Upper Queen 1854-1868' w/2 JSPF, total 28 holes.
- 19) Set packer at 1820'.
- 20) Acidized w/2000 gals. 15% NE acid using 56 ball sealers.
- 21) Flowed well back and recovered 15 bbls. fluid.
- 22) Swab tested well. Swab test indicated this interval to be water productive with only slight show of oil.
- 23) POH w/packer and RBP. Released rig and moved off location 6-9-81.
- 24) Waiting on pumping unit & tank battery installation.