

<u>DEPTH INTERVAL FROM-TO</u>	<u>WEIGHT LBS/CAL</u>	<u>TYPE</u>	<u>OIL %</u>	<u>pH</u>	<u>WATER LOSS (cc)</u>	<u>VIS. (sec.)</u>	<u>YIELD POINT</u>	<u>THINNING AGENTS</u>	<u>WATER LOSS AGENTS</u>
0'-500'	8.5-9.0	Spud							As needed
500'-1200'	8.5-9.0	Fresh water							As needed
1200'-7500'	8.5-8.8	Fresh water							As needed
7500'-9800'	8.5-8.9	Fresh water Low solids Polymer		+10.5	5 to 10	38 to 40			As needed

REMARKS

1. Drill out intermediate with fresh water.
2. Add sufficient gel to carry cuttings.
3. Lower viscosity and yield point prior to cementing.
4. Pressure surge to be kept to a minimum.