

- 10) SITP 215#. RU to swab. FL 1400'. Swabbed 2 BPH, 60% oil cut. FL 1900' F.S.
- 11) SITP 220#. Bled down. Reset RBP at 2230' and packer at 2130'. Fracture treated Lower Grayburg perfs. 2137-2187' w/14,000 gals. gelled water & 30,000# 20/40 sand. SI for 2 hours.
- 12) Reset RBP at 2130' and packer at 2024'. Fracture treated Upper Grayburg perfs. 2069-2107' w/14,000 gals. gelled water and 30,000# 20/40 sand.
- 13) SITP 0#. POH w/RBP and packer and tubing. Ran 69 jts. (2222') new 2-3/8" OD 8RD EUE J-55 tubing and set at 2230' KB.
- 14) RU to swab. FL at surface. Made 20 swab runs, recovered approximately 160 BW.
- 15) SITP 0#. FL 2000'. Made 2 swab runs, recovered approximately 16 BF, all water.
- 16) Ran rods and pump and hung well on 2-17-82.
- 17) Pump testing, making 126 BO, 276 BLW.