

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088
RECEIVED

NOV 18 1991

WELL API NO. 30-015-24157
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-8096
7. Lease Name or Unit Agreement Name Conoco "7" State
8. Well No. 11
9. Pool name or Wildcat E. Millman (Queen-Greyburg)
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3369.8' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator Mitchell Energy Corporation ✓
3. Address of Operator P. O. Box 4000, The Woodlands, TX 77387
4. Well Location Unit Letter <u>H</u> : <u>1980</u> Feet From The <u>North</u> Line and <u>560</u> Feet From The <u>East</u> Line Section <u>7</u> Township <u>19S</u> Range <u>29E</u> NMPM <u>Eddy</u> County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plug and Abandon as per the following procedure:

POOH w/rods, pump, and 2 3/8" tbg. RIH w/tbg and set ^{25SX} 35" cmt plug in 4 1/2" csg above top perf (2149'). Tag plug. Spot 25 sx plug @ top of Queen (1807'). Spot 25 sx plug at base of salt (691'). Spot 25 sx plug @ 8 5/8" shoe (369') and tag. Spot 10 sx cmt plug @ surface. Weld on cap and erect permanent abandonment marker. Load hole with gelled brine between all plugs.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE James Blount TITLE Engineer DATE 11/13/91
TYPE OR PRINT NAME James Blount TELEPHONE NO.

(This space for State Use)

APPROVED BY James Blount TITLE Engineer DATE 11-21-91
CONDITIONS OF APPROVAL, IF ANY

Plugging