

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

RECEIVED

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

NOV 18 1991

2. Name of Operator

Siete Oil and Gas Corporation ✓

O. C. D.
ARTESIA OFFICE

3. Address and Telephone No.

P.O. Box 2523, Roswell, NM 88202-2523

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Sec. 24, T18S, R31E
890' FNL & 990' FEL
NE $\frac{1}{4}$ NE $\frac{1}{4}$, Unit Letter A

5. Lease Designation and Serial No.

NM-025777

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Geronimo Federal #3

9. API Well No.

30-015-25385

10. Field and Pool, or Exploratory Area

Shugart Delaware E.

11. County or Parish, State

Eddy NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☐ Notice of Intent
☒ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☒ Other *perb*
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

9/14/91 TOH w/rods & tbq, TIH w/pressure bombs & pkr to 4970' & set, SI for buildup.
9/16/91 Start flwg well dn, unseat pkr, TOH w/pressure bombs, TIH w/perf guns, reset pkr @ 5073', pressure test pkr to 750 psi, held ok, start swabbing to SN, well built up w/paraffin, HO, TOH w/perf guns & pkr, SION.
9/17/91 TIH w/tbq & SN, swab to SN, TOH, TIH w/pressure bombs, perf guns & pkr, set pkr @ 5085.81', pressure test pkr to 600 psi for 5 min, pkr holding, SION.
9/18/91 Swab fluid dn to SN, perfed 5170'-5189', SION.
9/19/91 TIH w/swab, pull sample, TOH w/bombs, guns & pkr.
9/20/91 TIH w/bombs, guns & pkr, set pkr @ 5196.4', test pkr to 750 psi for 5 min, holding ok, swab to SN, perfed 5221'-5258', SI for pressure buildup.

14. I hereby certify that the foregoing is true and correct

Signed *C. Bartley-Seely*

Drilling Technician

Title

10/30/91

Date

(This space for Federal or State office use)

Approved by

Conditions of approval, if any:

Title

Date