NAME OF DATE RAN 48 JOINTS, 2008 FEET (TOTAL FOOTAGE RAN) OF 85/8 155 (size) (make) (weight) (type) CASING. SET GUIDE SHOE AT ______FEET. SET FLOAT AT FEET. SET & CEMENTED AT 1995 FEET WITH <u>43</u>0 lete ____SACKS OF __ CEMENT (type of cement) WITH 1/4 # cellaflake, 8# Salt (list all additives to cement) PLUS ______ SACKS OF _____ CEMENT WITH_ 2º? Cacl PLUS ______SACKS OF _____ CEMENT WITH____ time) (circle one) PLUG DOWN AT ____ 3-2 (date) (if cement did not circulate - describe fully your operations) PRESSURED UP TO _____FOR _____MINUTES, HELD OK? ______ WOC _____HOURS. REMARKS:_____