

Operator BROTHERS Production Co., Inc.  
 Well Tamane UT # 506  
 Unit N Section 11 Township 18 Range 31  
 API # 30-015-25897

# TOPS

<u>Rustler</u>	<u>780'</u>
<u>Salado</u>	<u>~1020'</u>
<u>Base Salt</u>	<u>~2045'</u>
<u>Gates</u>	<u>2215'</u>
<u>O'Brien</u>	<u>3368'</u>
<u>Grayburg</u>	<u>3910'</u>
<u>San Andres</u>	<u>4370'</u>
<u>Delaware</u>	<u>4720'</u>
<u>Bravo Spring</u>	<u>5885'</u>

- \* Contact OCD 24 hrs. prior to any work done.
- \* Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- \* Install dry hole marker as per Rule 202.B.2
- \* Plugs are to be set from point indicated up.
- \* Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- \* Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- \* Surface plug will be from 0' - 60'
- \* Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- \* Plugs to be tagged will be indicated.