

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

CONTACT RECEIVING

NM OIL & GAS COMPLETION
OFFICE FOR NUMBER
OF COPIES REQUIRED
Draw other instructions on re-
verse side)

BLM Roswell District
Modified Form No.
NM060-3160-4

dsf

SUNDRY NOTICES AND REPORTS ON WELLS RECEIVED

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER		NOV 20 '89		5. LEASE DESIGNATION AND SERIAL NO. NM-26864	
2. NAME OF OPERATOR Yates Petroleum Corporation ✓		3a. Area Code & Phone No. 505 6748-1471		6. IF INDIAN, ALLOTTEE OR TRIBE NAME N/A	
3. ADDRESS OF OPERATOR 105 South 4th St., Artesia, NM 88210		ARTESIA, OFFICE		7. UNIT AGREEMENT NAME N/A	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 1980' FNL & 1980' FWL, Sec. 24-19S-24E				8. FARM OR LEASE NAME Roden GD Federal Com	
14. PERMIT NO. 30-015-26096		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3601' GR		9. WELL NO. 3	
				10. FIELD AND POOL, OR WILDCAT Und. Hoag Tank Morrow	
				11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Unit F, Sec. 24-19S-24E NMPM	
				12. COUNTY OR PARISH Eddy	
				13. STATE NM	

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETE <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>

SUBSEQUENT REPORT OF:

WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>

(Other) Temporarily abandon Morrow w/
Standing Valve RBP

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

Propose to temporarily abandon Morrow perforations 8897-8907' as follows:
Set standing valve in on/off tool. Load tubing, Install BOP. Unlatch tubing at on/off tool.
POOH. RIH w/RBP, set at about 7770'. Perforate Canyon at 7636-40' (1 SPF-5 holes) and
7726, 27, 28, 29, 31, 32, 35, 37, 38, 39, 40, 43, 44, 46, 47 (1 SPF-15 holes). Treat perfs
7726-47' w/3000gals 20% NEFE acid. Treat perfs 7636-40' w/1000 gals 20% NEFE acid.
Reset RBP at about 8780' and test. Set packer at about 7600'. Swab back load and get
stabilized flow rate.

18. I hereby certify that the foregoing is true and correct

SIGNED [Signature]

TITLE Production Supervisor

DATE 11-6-89

(This space for Federal or State office use)

APPROVED BY _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE PETROLEUM ENGINEER

DATE 11-13-89

*See Instructions on Reverse Side

RECEIVED

NOV 7 11 12 AM '89