

Neely Com. No. 2 Recommended Procedure
Page 2

17. Flow test well , evaluate, and stimulate if necessary.
18. RDPU. Clean and level location.
19. Run C.A.O.F.P. and pressure build up.
20. Connect surface equipment.

TET
(NeelyCom1drlgprc)