

Neely Com. No. 2 Recommended Procedure
Page 2

16. RIW with packer, T.O.S.S.D. with "F" profile nipple and 2-3/8" tubing. Set packer, install flow tree, swab down tubing and perforate pay interval.
17. Flow test well , evaluate, and stimulate if necessary.
18. RDPU. Clean and level location.
19. Run C.A.O.F.P. and pressure build up.
20. Connect surface equipment.

TET
(Gossett202drlgprc)