

TOPS

Salado	~	485'
Base Salt	~	637'
Gates	~	750'

C^{3/4} @ 260'

← 60' Surface Plug.

8 5/8" @ 475'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

← 525' - 210' shoe Plugs. / Top salt Plug. TAG

7" @ 752'
40 5x5

← 802'-637'. Shoc Plug / Base Salt Plug. TAG

882'-TD

MS