

TOPS

← 60' surface plug.

Salada	481'
Base Salt	657'
Yarnes	~ 775'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

No Casing Records.
Procedure May
Change.

← 481' Cement Plug Inside & Outside 9" casing. Top Salt Plug. TA4

7" csg to 765'
w/ 100 sxs cmt.
8 5/8" hole

← 815'-652'. shoe Plug / Base SALT Plug. TAG

ID - 860'

MS