

Operator Ready Oil & Gas Mgt.
 Well Will Federal #16
 Unit M Section 13 Township 2c Range 28
 API # 30-013-02370

TOPS

Saleado ~ 450'
Base Salt ~ 650'
4500 ~ 800'

← Surface Plug

← Plug 450' Tag

← 305X Plug 731'-631' Tag

7" @ 681'
 125 SXS
 CIRC?

4 1/2" @ 1242'
 CIRC

← 305X Plug 1242' Tag

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

10