

Operator Neady Oil & Gas Mngt
Well Willis Federal #18
Unit M Section 13 Township 20 Range 28
API # 30-015-C2372

TOPS

Salado ~ 425'
Base Salt ~ 600'
Gates ~ 750'

← 60' Cement Surface Plug.

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

?

← 425' Cement Plug inside outside Csg. TAG
Top of SALT Plug.

← 840' - 600' TAG shoe Plug / Base SALT Plug.

No Records.

Procedure May
change.