

Operator Ready Oil & Gas Mngt.  
Well Wills Federal #21  
Unit 6 Section 13 Township 20 Range 28  
API # 30-015-02375

TOPS

Salado ~450'  
B Salt ~625'  
Gates ~775'

← Surface Plug

← Plug 450' Tag

- \* Contact OCD 24 hrs. prior to any work done.
- \* Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- \* Install dry hole marker as per Rule 202.B.2
- \* Plugs are to be set from point indicated up.
- \* Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- \* Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- \* Surface plug will be from 0' - 60'
- \* Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- \* Plugs to be tagged will be indicated.

7' @ 732  
ISC SXS

← Plug 725' Tag

TD - 854'