

## TOPS

Salade	470'
Salt	640'
Gates	2750'

← 60' surface Plug.

Cal. T.O.C. 196'

← 470'

### Cement Plug Inside & Outside\*

TAG Top of SALT Plug.

- \* **Contact OCD 24 hrs. prior to any work done.**
- \* **Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.**
- \* **Install dry hole marker as per Rule 202.B.2**
- \* **Plugs are to be set from point indicated up.**
- \* **Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.**
- \* **Shoe and stub plugs will be 50' above and below shoe or stub and tagged.**
- \* **Surface plug will be from 0' - 60'**
- \* **Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.**
- \* **Plugs to be tagged will be indicated.**

← 779' - 640'. Shoe Plug / BASE SALT Plug. TAG

7" @ 729'  
150 x 5  
Hole 8 3/4"

TD-854'

WS