

Operator Ready O & G
 Well Wills Fed. #30
 Unit H Section 13 Township 20 Range 28
 API # 30-015-06191

TOPS

Salado 490'
RSalt 692'
Yates ~ 775'

1 JT. 7" →
 25 7/8" Conductor pipe ← 60' Surface plug

480' ← EST. TO C
 Cement perfs - ran 3255%
 Perfs would not hold
 Pressure after cement job.

← 490' TAG

← 800' TAG

847' -
 862' ← Perfs

4 1/2"
 884'

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

MLB