

ATTACHMENT 1

Item 13 (continued)

N. Indian Basin Unit No. 1

7. RU swab. Swab well in. Start flowing well to test. RDMO pulling unit.
8. RU wireline. RIH and set 1.87" blanking plug in "F" nipple at 7505'. POOH. RIH w/shifting tool and opened sliding sleeve at 7344' to flow Upper Penn (7362'-7378') up tbg.
9. Start well flowing to test.