

## TOPS

TOC 83' →  
calc @ 50%

← 60 surface plug

Selade 440'  
B Salt 610'  
Gases ~ 770'

- \* Contact OCD 24 hrs. prior to any work done.
- \* Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- \* Install dry hole marker as per Rule 202.B.2
- \* Plugs are to be set from point indicated up.
- \* Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- \* Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- \* Surface plug will be from 0' - 60'
- \* Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- \* Plugs to be tagged will be indicated.

17" @ 161'  
15 SXS  
Est. 8 1/2' hole

Side plug TAG  
111' to 211'

← 440 TAG

544' ← TOC Calc @ 50%

700-16

5" 247'  
60 3x3  
8.5" hole

~~3~~ ALVZ  
847' TAG

TD 866

WLA