

30-015-10908 -

C-36-22-26

Corinne Drace

SALTY Bill #1 SWD

Tops

T. SALT - 650'

B. SALT - 1700'

T. Delav. - 1835'

* 10 sx surface Plug.

* Perforate 7 5/8" csg @ 414'. Squeeze 100' cement Plug
inside + outside 7 5/8" csg. TAH

* Perforate 7 5/8" csg @ 1700'. Squeeze 100' cement Plug
inside + outside 7 5/8" csg. TAH

* Circulate brine gel.

* Run + set CIBP @ 1900' w/ 35' cement.

13 3/8" csg
@ 364'
irc.

"hole

7 5/8" csg TD 2208'

@ 1948'

w/ 200' cl. H. cement.

1.18	2208
<u>x 200</u>	<u>- 1892</u>
236	
<u>x 8.0206</u>	366' cal. Tot
1892'	