

ATTACHMENT TO C-103

PAGE 4

- 12/7/00 SITP 50#. Bled gas off in 5 minutes. RU swab. IFL @ 3500'. Made 30 swab runs for the day and recovered 140 bbls of water. LTRC 415 BBLS. FFL @ 3500'. Trace if gas with swab run. No oil shows.
- 12/8/00 SITP 12#. Bled gas off in 5 mins. RU swab. IFL @ 3500'. Made 33 swab runs for the day and recovered 150 bbls of water. LTRC 265 bbls. FFL @ 3500'. Trace of gas with swab run. Tbg on vacuum after run. No oil shows.
- 12/9/00 SITP 15#. Bled gas off in 5 mins. RU swab. IFL @ 3500'. Made 23 swab runs for the day and recovered 120 bbls of water. LTRC 145 bbls. FFL @ 3500'. Show of gas with swab run. Tbg on vacuum after run. No oil shows.
- 12/10/00 Shut down for Sunday.
- 12/11/00 SITP 30#. Bled gas off in 5 mins. RU swab. IFL @ 3500'. Made 28 swab runs for the day and recovered 140 bbls of water. LTRC 5 bbls. FFL @ 3500'. Show of gas with swab run. Tbg on vacuum after run. No oil shows.
- 12/12/00 SITP 15#. Bled gas off in 5 mins. RU swab. IFL @ 3500'. Made 29 swab runs for the day and recovered 140 bbls of water. Have recovered a total of 735 bbls water. FFL @ 3500'. Show of gas with swab run. Tbg on vacuum after run, no oil shows.
- 12/13/00 SITP 15#. Bled gas off in 4 mins. RU swab. IFL @ 3500'. Made 14 swab runs for the day and recovered 70 bbls of water. Have recovered a total of 805 bbls water. FFL @ 3500'. Show of gas with swab run. Tbg on vacuum after run. No oil shows. Release packer and POOH with tubing. RU Computalog. RIH and tag PBDT @ 11167'. Dumped 1 sx cement @ 11167'.
- 12/14/00 RIH with GR-CCL tool. Tag PBDT @ 11167'(WL). Logged GR-CCL from 11167'- 10900'. Dumped 2 sx cal seal @ 11167'(WL). Waited 1½ hrs. RIH with GR-CCL and tagged PBDT @ 11162'(WL). Dumped 2 sx cal seal @ 11162'(WL). Waited 1½ hrs. RIH with GR-CCL and tagged PBDT @ 11162'(WL).
- 12/15/00 PU seating nipple, 109' of tail pipe, 5½" Arrow set packer and RIH with 346 joints of 2-3/8" tubing. Set packer @ 11041' with 10 pts compression. Seating nipple @ 11158'. RU swab. IFL @ 3500'. Made 12 swab runs and recovered 60 bbls water. FFL @ 3500'. No oil or gas shows. Dumped 3-sx 20/40 sand down tubing.
- 12/16/00 SITP 30#. Bled off gas. Released packer and tagged PBDT @ 11161'. POOH with tubing. RU Computalog. RIH with dump bailer and spotted 1 sx cal seal. Waited 1½ hrs. Tagged PBDT @ 11156'.
- 12/17/00 Shut down for Sunday.
- 12/18/00 PU seating nipple, 77' of tail pipe, 5½" Arrow set packer and RIH with 346 joints of 2-3/8" tubing. Set packer @ 11041' with 10 pts compression. Seating nipple @ 11126'. RU swab. IFL @ 3000'. Made 12 swab runs and recovered 60 bbls water. Trace of gas with swab run. FFL @ 3500', no oil shows. Dumped 3½ sx 20/40 sand down tubing.
- 12/19/00 SITP 50#. Bled gas off in 5 mins. Release packer and POOH with tubing. RU Computalog. RIH with dump bailer and tagged @ 11136'. Dumped 2 sx 12/20 sand and capped with 1 sx cement. Tagged PBDT @ 11120'.
- 12/20/00 PU 2 3/8" seating nipple, 43' of tail pipe, 5½" Arrow set packer and RIH with 346 joints of 2-3/8" tubing. Set packer @ 11041' with 10 pts compression. Seating nipple @ 11092'. RU swab, IFL @ 3600'. Made 3 swab runs and recovered 18 bbls water. Had a show of gas with swab runs. Parted swab line on 3RD run. Released packer and POOH with tubing. Found swab tools @ 6500'. Had 10 joints of tubing full of sand below swab tools. Finish POOH with tubing.