

TOPS

- * **Contact OCD 24 hrs. prior to any work done.**
- * **Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.**
- * **Install dry hole marker as per Rule 202.B.2**
- * **Plugs are to be set from point indicated up.**
- * **Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.**
- * **Shoe and stub plugs will be 50' above and below shoe or stub and tagged.**
- * **Surface plug will be from 0' - 60'**
- * **Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.**
- * **Plugs to be tagged will be indicated.**

2001