

Operator Ready Oil & Gas Mngt.
 Well Willis Federal #45
 Unit G Section 13 Township 2c Range 28
 API # 30-015-20231

TOPS

Salade ~ 450'
B Salt ~ 625'
Gates ~ 775'

TOC 96' →
 calc. @ 50%

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

7" @ 168'
 15 SXS
 8 5/8" hole

Shoe Plug
 118' to 218' TAG

370' ← TOC calc @ 50%

← 450' TAG

← 700' TAG

5" @ 802'
 50 SXS.
 6 1/4" hole

← 802' TAG

834' TD

MLB