

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN CERTIFICATE
(Other instructions on re-
verse side)

Form Approved
Project Number 100-100-100

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. ☐ OIL WELL ☐ GAS WELL ☐ OTHER	
2. NAME OF OPERATOR P. O. Corporation	
3. ADDRESS OF OPERATOR P. O., Hobbs, New Mexico 88240	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 600' FWL & 1650' FWL, Section 35, 20-S, 26-E	
14. PERMIT NO.	15. ELEVATIONS (Show whether DP, RT, GR, etc.) 3252' OL

5. LEASE DESIGNATION AND NUMBER
6. IF INDIAN, AGENCY OR TRUST NAME
7. UNIT AGREEMENT NAME Springs Unit
8. FARM OR LEASE NAME
9. WELL NO. 5
10. FIELD AND COO, CO. NUMBER Wildcat
11. SEC. T. R. M. OR SURVEY OR AREA Sec 35, 20-S, 26-E
12. COUNTY OR PARISH

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF	☐	PULL OR ALTER CASING	☐
FRACTURE TREAT	☐	MULTIPLE COMPLETE	☐
SHOOT OR ACIDIZE	☐	ABANDON*	☐
REPAIR WELL	☐	CHANGE PLANS	☐
(Other) Plug back & complete in Delaware			

SUBSEQUENT REPORT OF:

WATER SHUT-OFF	☐	REPAIRING WELL	☐
FRACTURE TREATMENT	☐	ALTERING CASING	☐
SHOOTING OR ACIDIZING	☐	ABANDONMENT*	☐
(Other)			

(NOTE: Report results of multiple completion or Completion or Recompletion Report and Log local.)
Completion or Recompletion Report and Log local.
Completion or Recompletion Report and Log local.
Completion or Recompletion Report and Log local.

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of completion of proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and points pertinent to this work.)*

6135' TD, 7316' PB.

Pull producing equipment. Set CI BP at 7575' and cap with 35' cement plug. Set 35' cement plug across 5-1/2" casing at approximately 7000'. Spot 100' cement plug across 5-1/2" casing stub. Spot 100' cement plug across First Bone Springs 2 1/2" casing from 2700' to 2800'. Spot 100' cement plug from 2700' to 2800', across 8-5/8" shoe at 2700'. Replace hole with brine water. Perforate 8-5/8" casing with 2, 1/2" JUMP in the 1930' to 2510'. Treat new perforations with 3000 gallons of 15% HCl. Swab and clean up and place well on production.

RECEIVED

NOV 5 1971

O. C. C.
ARTESIA, OFFICE

RECEIVED

NOV-4 1971

U. S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO

18. I hereby certify that the foregoing is true and correct

SIGNED: C. F. KALTEYER

TITLE: Area Engineer

DATE: November 4, 1971

(This space for Federal or State office use)

APPROVED
NOV 5 1971

APPROVED BY: R. L. BECKMAN

TITLE

DATE

R. L. BECKMAN
ACTING DISTRICT ENGINEER

*See Instructions on Reverse Side