drilling into the <u>Wolfcamp formation</u> and used until production casing is run and cemented. Monitoring equipment shall consist of the following:

- (1) A recording pit level indicator to determine pit volume gains and losses.
- (2) A mud volume measuring device for accurately determining mud volume necessary to till the hole on trips.
- (3) A clow sense on the clow-line to warn of any abnormal mud returns from the well.
- 6. When coming cot of the hole with dvill pipe, the annulus shall be filled with rud before the mud level drops below 150 feet. The volume of mud required to fill the hole shall be watched, and any time there is an indication of swabbing, or influx of formation fluids, proper blocket prevention precautions must be taken. The mud shall not be circulated and conditioned except on or near bottom, unless well conductors prevent running the pipe to bottom.
- 7. A copy of these requirements shall be posted on the rig floor or in the dog house during the dril way of the well.

A Level Andre 19 . Cagineer

Lease No. Well	David Fasten (-11 Paso "3" Cerai
Drillsite	2724/5 2870/E 101 11-3-215-16E
Depth	11,100' Morrow
Approved	7-20-73