

Operator Concho Petroleum, Inc.
 Well Cedar Spring #1
 Unit K Section 1 Township 21 Range 27
 API # 30-015-20955

TOPS

Reston	539'
Capital	~ 711'
Base Reef	~ 2500'
Delaware	2861'
Base Spring	5310'
Wolfcamp	8979'
Penn	9931'
Strawn	10160'
Atoka	10549'
Morrow Limestone	11040'
Morrow Clastics	11218'

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.