November 198 Formerly 9–3	31) DEPARTMENT OF THE INTERIOR Verse side)	bTE* bn re- Budget Bureau No. 1004-0135 Expires August 31, 1985 5. LEASE DEBIONATION AND BERIAL NO. NMNM77956	
(Do not	SUNDRY NOTICES AND REPORTS ON WELLS use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT—" for such proposals.)	6. IF INDIAN, ALLOTTEE OR TRIBE NAME Server # 1531	
		D 7. UNIT AGREEMENT NAME	
MANE OF OF Merit Er	mergy Company ARL MAY 1 3		
12221 M€	erit Drive, Suite 500, Dallas, TX 75251 O.C.C		
LOCATION OF WELL (Report location clearly and in accordance with any State requirements." See also space 17 below.) At surface SE 1/4 of NE 1/2		10. FIELD AND FOOL, OR WILDCAT Burton Flat (Atoka) 11. SEC., T., R., M., OR BLR. AND SUBVEY OR AREA	
4. PERMIT NO.		Sec. 4 T21S R <b>2</b> 7E	
	15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3183 GR	12. COUNTY OB PARISH 13. STATE Eddy NM	
8.	Check Appropriate Box To Indicate Nature of Notice, Repor	t, or Other Data	
FRACTURE ? SHOOT OR A REPAIR WEI (Other) 7. DESCRIBE PR proposed	CIDIZE ABANDON <sup>•</sup> CHANGE PLANS COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent work. If well is directionally drilled, give subsurface locations and measured and trans-	ng ABANDONMENT <sup>•</sup> mpletion Report X results of multiple completion on Well Recompletion Report and Log form.)	
4-29-92	Tbg press. 22 lbs; RIH w/swab & made 2 swab runs. R well 1.1 bbl/min. @ 4600# & 40 balls. 1000 gals 15 flush; FSP 4400; 5 min 4100; 10 min 3900; 15 min 37 flowing back well. RU swab. RIH w/swab & swab. Retr total bbls. RDWSU. RU swab unit. SI. Lost well on 1	nade 2 swab runs. RD swab. RU Acid trucks. Acidiz alls. 1000 gals 15 % NEFE acid; 43.5 bbls 2% KCL nin 3900; 15 min 3700. RD acid trucks. Start v/swab & swab. Retrieve 58.45 bbls. Load was 68	
4-30-92	110# tbg. RIH w/swab. FL @ 4200'. Swab back 5.35 bb Put on line.	Swab back 5.35 bbls wtr, 1 bbls short of load.	
5-1-92	-1-92 Swab well. Swab 3.3 bbls wtr; 4.9 bbls oil. FL @ 5200'. Swab well to seat nipple Not much blow. SI for build up.		
5-2-92	17 hrs SI. Tbg press 1560. Put well on line. In 2 h press of 50 lbs. Left well on line.	1560. Put well on line. In 2 hrs well pulled dwn to line well on line.	
5 2 72			
5-3-92	113.7 MCF; 3.3 wtr; 0 oil.	ACCESSION AND AND AND AND AND AND AND AND AND AN	
	113.7 PKF; 3.3 wtr; 0 oil.		
5-3-92		ACCOUNT STORE	
5-3-92	tify that the foregoing is true and correct	DATE 5-5-92	
5-3-92 8. I hereby cer SIGNED		DATE 5-5-92	

## \*See Instructions on Reverse Side