

Operator Marathon Oil Company
 Well Yaros Federal #3
 Unit E 1 Section 17 Township 2c Range 29
 API # 30-015-20969

TOPS

Salt	SCC-840
Regt	~ SCC-3000
Delaware	3130
Bone Spring	6140
Wolfcamp	29200
Penn	9980
Strawn	10257
Atoka	10625
Marathon LS	11203
Marathon CI	11361

- * Contact OCD 24 hrs. prior to any work done.
- * Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- * Install dry hole marker as per Rule 202.B.2
- * Plugs are to be set from point indicated up.
- * Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- * Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- * Surface plug will be from 0' - 60'
- * Where plugs are required, cement must be placed inside and outside of all casing string(s) in the correct footage or sacks required, if no cement exists.
- * Plugs to be tagged will be indicated.

← 60' Surface Plug.

← 667' Shoe Plug TAG

← 900' TAG

Shoe + Top Perf Plug.
 ← 3220' - 3058' TAG

Perf - 3320' - 42'

PBTD - Est. 3569'

13 1/8" @ 617'
CIRC

8 5/8" @ 3103
CIRC

4 1/2" @ 11751