

13. Con't.

05-11-94 STUNG INTO RETAINER. MIX & PUMP 100 SX "C" NEAT 1634 PPG. UNABLE TO PUMP INTO @ 1000 PSIG. PULL OUT OF RETAINER. PUT 25 SX CMT ON TOP OF RETAINER. SPOT 35 SK PLUG @ 730-600'. SET CMT PLUG 50' TO SURFACE. CUT OFF CSG. INSTALL DRY HOLE MARKER. RDMO.