



1 Run Bridge plug & RTTS
To About 3000 ft.

2. Set Bridge Plug & Test

3. Pull RTTS Packer up
Hole to Test for Hole

4. After Locating Hole
if up in surface pipe
it would be better
to back off $5\frac{1}{2}$ Casing
and replace with good
Casing.

5. If Hole is deep we
will Half to Cement

6. volume would be
between Casing and Hole
+ 75%.

Class "C" with 10th salt
Tail in with 75 sks of
Class "C" 2% Calcium
Chloride

Sand on top of Plug if Cemented

Bridge Plug

Pump Truck.

549.00

Tools

831.00

Pay zone