

2/9/76

Well closed in this AM. Slight blow on csg. & tbg. Rig Otis wireline unit & go in hole with equalizing prong for packer setting tool & equalize. Make three runs with Otis overshot to retrieve packer setting tool. Shear pin in overshot on first two runs. Retrieve packer setting tool on third run. Rig to swab, make 11 runs with swab in 4 hrs. Well kicks off to flow, leave well flowing to tank on 3/4" choke unloading water with gas.