## LIVINGSTON RIDGE UNIT #1 Sec. 36, T21S, R30E EDDY COUNTY, NEW MEXICO

- Nov. 10, 1975 Road to lease. Finish running 2 7/8". Space out. Rig up to run 2 1/16" start running pipe and short string stinger. Shut down.
- Nov. 11, 1975 Road to lease. Finish running 2 1/16". Set packers. Remove B.O.P. install tree.
- Nov. 12, 1975 Road to lease. Set packer and test. Displace hole with condensate Flow back Start swabbing. Shut down.
- Nov. 13, 1975 Drove to location. Started swabbing long string. Found tight spot in 2 7/8" 6,500" down. Rigged up to swabbwd 2 1/16" tubing. Shut down for the day.
- Nov. 14, 1975 Road to lease. Swab well to pit. Shut down.
- Nov. 15, 1975 Road to lease. Test packers and test for leaks. Shut down.
- Nov. 16, 1975 Road to lease. Complete tests on packers and tubing. Shut down.
- Nov. 17, 1975 Road to lease. Swab long string. Remove tree, install B.O.P. start out of hole with short string.
- Nov. 18, 1975 Road to lease. Pull short string. Rig to pull long string. Unseat packer. Shut down,
- Nov. 19, 1975 Road to lease. Pull long string. Get ready to run long string back Drove to location. Laid 10 jts. tubing down for derrick. Ran tubing on Baker packer.
- Nov. 20, 1975 Completed running 2 7/8" tubing on packer. Road to lease. Finish going in hole. Space out and land. Remove B.O.P. and install tree. Start swabbing. Swabbed well.
- Nov. 21, 1975 Swabbed well. Road to lease. Swab well. Shut down,
- Nov. 22, 1975 Road to lease. Make fluid level run with swab. Rig Halliburton up to treat well. Packer gave way. Stopped job.
- Nov. 23, 1975 Road to lease. Flow well to pit.
- Nov. 24, 1975 Road to lease. Blow well down. Swab well to pit. Shut down.
- Nov. 25, 1975 Road to lease. Blow well down. Swab to pit. Shut down.
- Nov. 26, 1975 Road to lease. Blow well. Swab to pit.
- Nov. 28, 1975 Road to lease. Swab well
- Nov. 29, 1975 Road to lease. Swab well to pit.
- Dec. 2, 1975 Road to lease. Blow well down. Start swabbing to pit. Well came in. Flowed well to pit. Shut down.
- Dec. 3, 1975 Road to lease. Swab and flow well to pit.
- Dec. 4, 1975 Read to lease. Blow well down. Swab to pit. Shut down.