

Attachment for Little Box Canyon Unit #1, dated 6/7/79

TD 8350' PBSD 7290.

1. MIRU pulling unit. NU BOP's. Circ hole w/2% KCL water. POOH w/OEd tbg.
2. RU Schlumberger. Perforate squeeze holes in 5½" csg 2 SPF @ 6089' & 5864' using 4" Hyper Jet II csg gun. Set 5½" EZ drill SV cmt retainer on wireline @ 6070'
3. GIH w/tbg & seal assembly. Stab into retainer & test tbg to 1000#. Open SV & try to break circ through perfs. Limit surface pressure to 2500#. If circ is established with sufficient rate, cmt w/100 sx Class H w/0.6% Halad 9 on circ type squeeze. Displace all but 2 sx cmt from tbg. Pick up out of retainer & dump remaining cmt on top. PU to + 5700' & reverse out excess cmt. POOH & WOC.
NOTE: If circ is not established, use block type squeeze on lower perfs with 50 sx Class H w/0.6% Halad
9. Use RTTS to block squeeze upper perfs with remaining 50 sx cmt.
4. RIH w/4-3/4" RB & DC's on 2-7/8" tbg. Drill out cmt & test squeezed perfs individually to 2500#. CHC & spot 150 gallons 10% acetic acid 5800 - 6100'. POOH
5. Run GR/CCL/CBL 5800 - 6100'. Perforate Cisco-Canyon 5864 - 6089' using 2 SPF & 4" Hyper Jet II csg gun. 5864, 5866, 5879, 5898, 5902, 5903, 5930, 5931, 5980, 5983, 5986, 5987, 5988, 5989, 5994, 6014, 6015, 6033, 6038, 6039, 6040, 6084, 6087, & 6089.
6. GIH w/Baker Lok-Set pkr on 2-7/8" tbg & set pkr at 5800'. Swab well down & test natural.
7. If necessary, RU & acidize.
8. Recover load & retest.
9. Run 4-point & BHP tests.

RECEIVED

JUN 11 1979

U.S. GEOLOGICAL SURVEY
ARTESIA, NEW MEXICO