:

۱<u>.</u>

(1/2 in and 1/2 out of 9-5/8" casing shoe @ 2989!). Set a 10 sack cement surface plug @ 58 - O' and installed a 4" dry hole marker extending 4" above the ground to designate a plugged and abandoned location.