

RECEIVED

JUN 14 1991

Attachment to Form C-101

O. C. D.
ARTESIA, OFFICE

Page 2 of 2

16. Latch onto on-off tool, press up on tbg to insure no communication or leaks.
17. RUWL, RIH, open sleeve and swab backside fluid level down until Canyon flows up backside.
18. After Canyon formation is producing, close sliding sleeve w/WL.
19. RIH w/WL and pull plug in the on-off tool.
20. Produce Morrow zone up the tbg and stabilize.