

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

RECEIVED

JAN 26 1981

O. C. D.  
ARTESIA OFFICE

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER-	7. Unit Agreement Name
2. Name of Operator TENNECO OIL EXPLORATION & PRODUCTION Co. ✓	8. Farm or Lease Name NORTH FORK
3. Address of Operator 6800 Park Ten Blvd., Suite 200 N., San Antonio, TX. 78213	9. Well No. /
4. Location of Well UNIT LETTER C, 1980 FEET FROM THE West LINE AND 660 FEET FROM THE North LINE, SECTION 2 TOWNSHIP 22S RANGE 25E NMPM.	10. Field and Pool, or Wildcat Catclaw Draw (Wolfcamp)
11. Elevation (Show whether DF, RT, GR, etc.) 3556' GR	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☐  
CHANGE PLANS ☐  
OTHER ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOBS ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☒

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well was plugged and abandoned as follows: (1) CIBP set at 10598' and 35' of cement dumped on top to plug the Morrow. (2) CIBP set at 9050' and capped with 35' of cement to plug the Penn. (3) CIBP set at 8600' and capped with 35' of cement to plug the Wolfcamp. (4) CIBP set at 8350' and capped with 35' of cement. (5) Freepoint 5 1/2" casing. Cut casing at 5582' and pulled. (6) Spot 150 sx CL "C" + 3% CaCl<sub>2</sub> from 7481 to 7350'. (131' plug). Tagged plug at 7350'. (7) Spot 25 sx CL "C" cement 5593'-5481' (112'). tagged plug @ 5481'. (8) Spot 35 sx CL "C" cement 4432' to 4294' (138'). (9) Spot 25 sx cement 2331-2237' (106'). Tagged plug at 2237'. (10) Spot 20 sx cement 1970-1870' (100'). (11) Spot 25 sx cement at surface (12) Erect dry hole marker (13) clean and level location. Cut off anchors.

I, I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Mary Hall TITLE PRODUCTION ANALYST DATE 12/29/80

APPROVED BY Mike Stullfeld TITLE OIL AND GAS INSPECTOR DATE JAN 26 1981

CONDITIONS OF APPROVAL, IF ANY: