

BLEDSON PETRO
LONE TREE #1

12. COMPLETED OPERATIONS

5. Perforated 2nd Bone Springs Sand 7456'-7462', 7473'-7477', & 7484-7498' with 2SPF.
6. Break down Bone Springs Perfs with 3000 Gal acid.
7. Swab back load water, dried up.
8. Evaluate for major stimulation.