

C-103 Lone Tree Cont.

2. Fill hole with mud
3. Pump 100" Cement plug 1150'-1250' (Top of Capitan Reef at 1200')
4. Place 3 sack cement plug at surface SSD-ft to 650 ft shoe plug
5. Cut off and weld metal plate on 13 3/8" surface csg.
6. Level and clean up location Estimated starting date 11/1/91