

COMPANY MWJ		PROPERTY NAME State 6W #1		WELL NO. 1
DATE 7-19-96	LOCATION (ULSTR) K-36-20-27		FOOTAGE 1980 FSL + WL	
API NO. 30-015-21949		POOL N. Burton Flats WC		

Set CIBP and cap w/ 35' cement spot
a 35' plug + tag.

If 4 1/2 is not pulled, perforate @ 2450 +
pump enough cement to leave 100' inside
& outside of 4 1/2 across 8 5/8 shoe + tag
Spot 25' plug inside 4 1/2 @ 500'

Spot a 10' surface plug + set PA marker
If 4 1/2 is cut + pulled spot plug 50' in & out
of easy stub + tag.

Spot a 100' plug across 8 5/8 shoe + tag
Spot a 100' plug across 13 3/8 shoe + tag
Spot a 10' surface shoe + Set PA marker

Salt gel 25 lb per bbl to be placed
between plugs.

CASING RECORD:

13 3/8 @ 500'

8 5/8 @ 2400'

4 1/2 @ 4755 W/TOC @ 3610

Dele 4560 T/Reef 6CS

Sa @ 4404 B/Reef 2400

Will spot cement plugs + tag
Will cut possibly around 3500'

13 3/8 @ 500'

8 5/8 @ 2400'

Tag
TOC 3610

Perfs @
4560-4618

PBTD 4 1/2
4755

This is P+H
@ 8000'