

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
Other instructions on reverse side

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

clsf

LEASE DESIGNATION AND SERIAL NO.

NM 18605

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL ☐ GAS ☒ OTHER ☐		RECEIVED JAN - 7 1992 O. C. O. ARTESIA OFFICE		5. IF INDIAN, ALLOTTEE OR TRIBE NAME	
2. NAME OF OPERATOR Enron Oil & Gas Company				7. UNIT AGREEMENT NAME	
3. ADDRESS OF OPERATOR P. O. Box 2267, Midland, Texas 79702				8. FARM OR LEASE NAME Federal RV 4	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also source 17 below.) At surface 1980' FEL & 660' FSL				9. WELL NO. 1	
14. PERMIT NO. 30 015 21981		15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3600' GR		10. FIELD AND POOL, OR WILDCAT Revelation Morrow	
				11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Section 4, T22S, R25E	
				12. COUNTY OR PARISH Eddy	
				13. STATE NM	

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐	PULL OR ALTER CASING ☐
FRACTURE TREAT ☐	MULTIPLE COMPLETE ☐
SHOOT OR ACIDIZE ☐	ABANDON* ☒
REPAIR WELL ☐	HANGE PLANS ☐
(Other) ☐	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐	REPAIRING WELL ☐
FRACTURE TREATMENT ☐	ALTERING CASING ☐
SHOOTING OR ACIDIZING ☐	ABANDONMENT* ☐
(Other) ☐	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

PROCEDURE CONFIRMED WITH JIM AMOS of the BLM on 11/27/91

1. Load hole with 10#/gal mud-laden fluid
2. Unseat Otis packer at 8665', pull out of hole with packer, on/off tool and tubing
3. Set a COBP by wireline at 8650' and dump 35' of cement on top.
4. Run freepoint on 5-1/2" casing.
5. Cut and pull casing at freepoint (+/- 8500')
6. Run in hole with 2-3/8" tubing, spot 100' across 5-1/2" casing cut (50' in and out of cut) - tag this plug.
7. Spot a 100' plug from 5300' to 5400'
8. Spot a 100' plug from 2370' to 2270' - tag this plug
9. Spot a 100' plug from 360'-260'
10. Spot a 50' plug at surface
11. Weld plate on head, clean up location. (OVER)

SIGNED Betty G. Gilson TITLE Regulatory Analyst DATE 12/3/91
Pre space for Federal or State office use:
APPROVED BY _____ TITLE _____ DATE 1/3/92
ADDITIONS OF APPROVAL, IF ANY:

*See instructions on Reverse Side

MAJOR GEOLOGIC MARKERS

3rd Bone Spring	7604'
Wolfcamp	7812'
Cisco Canyon	8552'
Strawn	9500'
Atoka	9708'
Morrow	10,433'

FEDERAL "RV" 4 #/ WELLBORE DIAGRAM

EXISTING

PROPOSED

