

9. N.D. and cut casing 3' below ground level. Weld steel plate w/well name on casing. R.D. and move off location.
10. Install dry hole marker consisting a steel marker at least four (4) inches in diameter set in concrete and extending at least four (4) feet above ground level. The name, number and location of the well must be welded, engraved or stamped on marker.
11. Clean up location and haul off equipment and junk. Notify landowner for permission to leave caliche material on road and location. If rejected, caliche should be picked up and hauled off.

009/AA