

Recommended Drilling and Completion Procedure
A.F.E. No. 411
Shell Federal Comm. No. 2

15. Run tubing, 2-3/8" EUE AB modified, and packer.
16. Swab well down.
17. Control pressure perforate with "thru-tubing" perforating gun.
18. Production test well.
19. Stimulate well as necessary.
20. Clean up treating fluid.
21. Flow test well.
22. Run C.A.O.F.P. and pressure build up.
23. Connect surface equipment.