

8. Swab down tubing as far as possible, drop bar to break glass disk, swab well in.
9. Flow well 1-2 days.
10. Flow back well to clean up and put down sales line.
11. Report production on Morning Report for 10-14 days.
12. Run BHP bombs and get a 3-day (72 hr) build-up test after well has cleaned up. This information will be used to determine if additional stimulation work is needed.

AFE99\1270B.KO.jey