

Procedure by JSS

FIELD: Burton Flat

Cherry Canyon was wet and was not fraced, clean out to CIBP and produce Upper Cherry Canyon. In either case, flow well or PWOP depending on productivity. Contact Jon Snell at 688-6244 if questions arise at this point in the procedure.

If no zones were found to be productive, RDMO WSU. A P&A procedure will be initiated.