

6/7/96: Flow to frac tank. Recovered 213 BW. Circ'd 78' of sand. Made 20 swab runs, rec. 140 BW. Parted sand line. POOH w/ tubing and TA. SN lost in hole.

6/9/96: Blow well down to frac tank. Made 4 swab runs and well kicked off flowing. Made 137 BO and 13 BW. Well dead at 5:00 p.m.

SI for weekend.

6/12/96: RIH w/ rods and pump. Spaced pump out.

6/26/96: Put well on production at 5:00 p.m.