

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Box 99, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Artesia, NM 87410

OIL CONSERVATION DIVISION
2040 Pacheco St.
Santa Fe, NM 87505

WELL API NO.	30-015-26280
5. Indicate Type of Lease	STATE ☐ FEE ☒
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	Lone Tree Federal Com
8. Well No.	1
9. Pool name or Wildcat	East Carlsbad Bone Springs

10. Elevation (Show whether DF, RKB, RT, GR, etc.)	3126 GL
--	---------

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL ☒ GAS WELL ☐ OTHER ☐	2. Name of Operator Collins & Ware, Inc.
3. Address of Operator 508 West Wall, Suite 1200, Midland, Texas 79701	4. Well Location Unit Letter N : 660 Feet From The South Line and 2120 Feet From The West Line Section 24 Township 21S Range 27E NMPM Eddy County
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3126 GL	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK ☐	REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐	ALTERING CASING ☐
PULL OR ALTER CASING ☐	COMMENCE DRILLING OPNS. ☐
OTHER: ☐	PLUG AND ABANDONMENT ☐
	CASING TEST AND CEMENT JOB ☐
	OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

We intend to plug and abandon the Lone Tree Federal Com #1 using the following procedure:

1. Set CIBP at +/- 6575'. Cap with 35' of cement.
2. Pull, stretch, and cut casing at free point.
3. Spot 25 sx cement plug in casing stub. 50' in and 50' out. Wait on cement and tag plug.
4. Spot 35 sx plug at 5430'.
5. Spot 35 sx plug at 2545'.
6. Spot 35 sx plug at 2308'. Wait on cement and tag plug.
7. Spot 35 sx plug at 709'. Wait on cement and tag plug.
8. Spot 10 sx surface plug. Weld on plate and install P & A marker.
9. Cut off anchors and clean location.

* Note: Mud between all plugs & mud out of well during Plugging Operations.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Dianne Sumrall TITLE Production Administrator DATE 11/17/98
TYPE OR PRINT NAME Dianne Sumrall TELEPHONE NO. (915) 687-3435

(This space for State Use)

APPROVED BY Mona Sturges TITLE Field Rep II DATE Dec. 14 98
CONDITIONS OF APPROVAL IF ANY: