

BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES & ID REPORTS ON WELLS

(This form shall be used for proposals to drill or to deepen or plug back any oil or gas well, or for an application for permit to drill or to deepen or plug back any oil or gas well.)

RECEIVED

DATE OF OPERATOR

MAR 11 1991

Siete Oil and Gas Corporation

ADDRESS OF OPERATOR

O. C. D.

P.O. Box 2523, Roswell, NM 88202-2523 ARTESIA, OFFICE

LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.)

At surface

2460' FNL & 330' FWL, SW $\frac{1}{4}$ NW $\frac{1}{4}$, Unit Letter D

DEPTH OF

11 ELEVATIONS (Show whether of, to, or on site.)
3828' GR

1. OF FORM, ALLOCATION (to State Dept)

NM-82853

2. DATE OF REPORT DATE

3. NAME OF LAND OWNER

Blackfoot Federal

4. WELL NO.

1

5. FIELD AND WELL, OR WILDCAT
Wildcat6. SEC. T. R. S. OR BLM AND
QUOTA ON AREA

Sec: 17, T22S, R25E

7. COUNTY OR PARISH
Eddy8. STATE
NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER DEPTH-OUT

☐
☐
☐
☐

FILL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANE

☐
☒
☐
☐

COMPLETION REPORT ON:

WATER DEPTH-OUT

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐

(Note: Report results of multiple completion on Well Completion or Description Report and Log form.)

DESCRIPTION PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and open ports (omit in this work).)

Surface: 13 3/8" csg set @ 400', cmt'd to surface.

Intermediate: 8 5/8" csg set @ 1698', cmt'd to surface.

T.D.: 7 7/8" hole @ 4261', PB 4133'-4033' w/30 sxs, PB 3120'-2945' w/85 sxs.

Production: 5 1/2" 15.5# set @ 2945', cmt'd w/315 sxs, PBTD 2895', CBL shows TOC in annulus @ 1250', perforations @ 2706' & 2696.5'.

Plugging Procedure: [Notify BLM] [use 9.0. ppq mud between plugs].

Set CIBP @ 2670', cut off 5 1/2" csg @ 1240' or freepoint, lay dn 5 1/2" csg, plug #1-10 sxs CC, plug on top of CIBP @ 1240', plug #2-30 sxs CC, plug from 1340' to 1190'=100' inside 5 1/2" & 50' inside 8 5/8" * plug #3-10 sxs CC, plug from 33' to surface, erect P&A marker.
50'

(SJS)

TAG PLUG.

* spot 100' cmt plug across 13 3/8" csg shoe

* NOTE: See Attached.

I hereby certify that the foregoing is true and correct

SIGNED

Cathy Batley-Soley

TITLE

Drilling Technician

DATE

2/18/91

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

3/7/91

CONDITIONS OF APPROVAL IF ANY:

*See Instructions on Reverse Side

WELL: Blackfoot Fed. #1
 LOCATION: 2466 FNL & 330' FNL [SWNW] of S17, T22S, R25E.
 LEASE NO.: NM-82853

AREA OF MAJOR CONCERN TO CBAD WATER SUPPLY

