Submit 3 Copies to Appropriate District Office	State of New Me Energy, Minerals and Natural Re			Form C-103 Revised 1-1-89
DISTRICT I	OIL CONSERVATIO	ON DIVISION	WELL API NO.	
P.O. Box 1980, Hobbs, NM 88240	P.O. Box 20			015-28619
DISTRICT II P.O. Drawer DD, Anesia, NM 88210	Santa Fe, New Mexico	87504-2088	5. Indicate Type	
DISTRICT III 1000 Rio Brazos Rd., Azzec, NM 87410			6. State Oil & Ga	
SUNDRY NOT	CES AND REPORTS ON WE	110		
(DO NOT USE THIS FORM FOR PRO DIFFERENT RESEF (FORM C		OR PLUG BACK TO A	7. Lease Name of	r Unit Agreement Name
1. Type of Well: Of WELL X WELL	OTHER		Moja	ve AJY Com
2. Name of Operator			8. Well No.	· · · · · · · · · · · · · · · · · · ·
YATES PETROLEUM CORPOR	RATION			3
3. Address of Operator 105 South Fourth Street - Artesia, NM 88210			9. Pool name or Wildcat	
4. Well Location	et - Artesia, NM 88210		Dagger Dra	w Upper Penn, South
Section 35 II. Check NOTICE OF IN	10. Elevation (Show whether 3717 Appropriate Box to Indicate	[•] GR Nature of Notice, F		Eddy County
NUTICE OF IN	IENTION TO:	- SUE	SEQUENTI	HEPORI OF:
	_			
		REMEDIAL WORK		ALTERING CASING
	PLUG AND ABANDON			ALTERING CASING PLUG AND ABANDONMENT
	—	REMEDIAL WORK	g opns.	
TEMPORARILY ABANDON	—	REMEDIAL WORK	g opns.	PLUG AND ABANDONMENT
TEMPORARILY ABANDON	CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER:Perfora and give perimens dates, incl % KCL water. Pi retrieving tool	G OPNS.	PLUG AND ABANDONMENT
TEMPORARILY ABANDON	CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER:Perfora and give perimens dates, incl % KCL water. Pi retrieving tool	G OPNS.	PLUG AND ABANDONMENT
TEMPORARILY ABANDON	CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER:Perfora and give perimens dates, incl % KCL water. Pi retrieving tool	G OPNS.	PLUG AND ABANDONMENT
TEMPORARILY ABANDON	CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER:Perfora and give perimens dates, incl % KCL water. Pi retrieving tool	G OPNS.	PLUG AND ABANDONMENT
TEMPORARILY ABANDON	CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Perfora and give pertinent dates, incl % KCL water. Pi retrieving tool d RBP. Released	G OPNS.	PLUG AND ABANDONMENT
TEMPORARILY ABANDON	CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Perfora and give pertinent dates, incl % KCL water. Pi retrieving tool d RBP. Released	G OPNS.	PLUG AND ABANDONMENT
TEMPORARILY ABANDON	CHANGE PLANS	REMEDIAL WORK COMMENCE DRILLIN CASING TEST AND C OTHER: Perfora and give pertinent dates, incl % KCL water. Pi retrieving tool d RBP. Released	G OPNS.	PLUG AND ABANDONMENT

INDC	VED	RY	_

- DATE -