

Catclaw Draw Unit #23-3

Attachment to Form C-103

On 12/22/97 Hallwood plugged and abandoned this well following these steps:

- 1) Set 4.5" cmt retainer at 2560'.
- 2) Established pump-in rate into perfs at 2626-2800' at 3.5 BPM at 860#.
- 3) Mix and pump 25 sxs cmt below retainer. Pulled out of retainer and pumped 30 sxs cmt on to of retainer.
- 4) POOH w/tbg & stinger, waited 3 hrs & went & logged cmt at 1821'.
- 5) POOH w/10 jts & circulated hole w/plug mud.
- 6) POOH to 308' and pump 25 sxs cmt & fill 4 ½" csg to surface.
- 7) Cut off casinghead, install dry hole marker, well is plugged.