


YATES PETROLEUM CORPORATION
Jacque AQJ State #1
Section 34-T21S-R31E
Eddy County, New Mexico

SUNDRY NOTICE CONTINUED:

10. Swab test.
11. Move RBP from 7450' to 6900'. Load casing with 2% KCL water. Test RBP to 2000 psi. TOOH with tubing.
12. Perforate 6777-6885', acidize and frac as necessary for production.
13. Swab test.
14. TOOH with all tools. Clean out sand fill to TD with open ended tubing.
15. Place well into production.



Rusty Klein
Operations Technician
April 23, 1999